

Install Centre Fixed Handles – Single sided

What is single-sided centre fixing?

A **centre fixing** is where there is one fitting located at the centre point of the handle.



Single-sided fitting is when the handle is fixed to the door face on one side of the door only.

This is not a concealed fitting, as the head of the screw will be seen on the rear of the door. However, this is the most common method for fixing joinery or cupboard handles.

What type of handles will have this type of fixing?

Any round joinery/cupboard handles that do not require a concealed fitting.

Hardware supplied

- 1 x 6mm metal threaded insert prefixed in the rear of each handle
- 1 x 6mm screw
- 1 x Allen key

Safety

- Always follow the manufacturer's safety instructions when using power tools and adhesives
- Wear safety glasses throughout the installation

Step 1: Set up

You will need

- 4-12mm drill, depending upon the size of the fitting
- Safety glasses
- Tape measure
- Pencil
- Small Allen key
- Handle and screw

NB: It is highly recommended you apply the finish of your choice to the handles prior to installation.

Step 2: Prepare the door

- a) Locate and mark the position of the handles on the door
- b) Drill an *8mm hole through the door at the point marked out above
**be sure to check the size of the fitting prior to drilling and check door hole sizes below*

Sizes (mm)		
Fitting	Door hole	Glass door hole
4	4-6	NA
6	8	10
8	12	14

Step 3: Install

- a) Insert the screw through the predrilled hole in the door from the rear side.
- b) On the other side of the door, wind the handle onto the screw. Tighten with the Allen key until secure, taking care not to over tighten.



c) take a snap and send it to us!



Image thanks to Teresa Kleeman at Embracing space

Image credit: [Embracing Space Interior Design](#)